



INSTRUCTION MANUAL

ANCHOR LOAD CELL

Model ANCLO

© Roctest Limited 2003. All rights reserved

This product should be installed and operated only by qualified personnel. Its misuse is potentially dangerous. The Company makes no warranty as to the information furnished in this manual and assumes no liability for damages resulting from the installation or use of this product. The information herein is subject to change without notification.

Tel. : 1.450.465.1113 • 1.877.ROCTEST (Canada, USA) • 33 (1) 64.06.40.80 (Europe) • www.roctest.com • www.telemac.com

TABLE OF CONTENTS

1	PRODUCT.....	1
1.1	DESCRIPTION.....	1
1.2	SPECIFICATIONS.....	2
2	INSTALLATION.....	2
3	DATA READING AND ANALYSIS	3
3.1	GENERAL	3
3.2	CALCULATING THE GAGE FACTOR.....	3
3.3	READING PROCEDURES	4
3.4	INTERPRETATION.....	5
3.5	VERIFICATION OF CELL CIRCUIT	5
4	MISCELLANEOUS.....	6
4.1	CONVERSION FACTOR.....	6
4.2	SAMPLE FIELD DATA SHEET	7
4.3	CALIBRATION DATA SHEET	8
4.4	WIRING DIAGRAM	9

1 PRODUCT

1.1 DESCRIPTION

The ANCLO load cell is built with a hollow cylindrical core onto which eight to sixteen strain gages are bonded in pairs at 90° intervals around the periphery. Load cells less than 152 mm in diameter use 4 pairs of bonded strain gages whereas 152 mm or larger diameter load cells use eight pairs of bonded strain gages. The gages are wired in a full bridge configuration for temperature compensation, optimum sensitivity and the accurate measurement of non-uniformly distributed loads. The lead cable connects to the cell by

- either a detachable multi-pin electrical connector mounted on the cell
- or permanent factory wiring of the lead cable to the cell. The cable enters the cell through a watertight electrical connector

The standard load cells are protected against moisture intrusion and are splash proof. They may be made submersible by using an underwater cable connector and stainless steel construction as opposed to the standard plated steel.

An identification plate on the outside of the cell holds the following information:

- The serial number
- The capacity of the cell in kN




FIGURE 1: Anchor load cell.

1.2 SPECIFICATIONS

SPECIFICATIONS

Model	Anclo Standard	Mini Anclo	Anclo/T	Anclo Split
Standard Construction				
Core:	Heat treated, black oxide, steel			
Housing:	Cadmium plated steel			
Environmental:	Corrosion resistant, watertight, weatherproof (submersible stainless steel optional)			
Cabling:	Detachable electrical connector or watertight cable connector			
Electrical configuration:	According to cell diameter Dia. 152 mm or less: 4 pairs of bonded strain gages, full bridge Greater than 152 mm: 8 pairs of bonded stain gages, full bridge			
Impedance:	700 Ω - 4 pairs or 1400 Ω - 8 pairs			
Excitation voltage:	2 to 10 volts - 2.0 volts (P-3500 readout) - 2.5 volts (SENSLOG data acquisition) - 10.0 volts (PC with M3C conditioner)			
Non-linearity:	$\leq 0.5\%$ F.S.			$\leq 1.0\%$ F.S.
Resolution:	0.1% F.S.			
Temperature sensitivity:	$\leq 0.01\%$ F.S./ $^{\circ}\text{C}$			
Overload capacity:	2 x rated capacity			
Operating temperature range:	-40°C to $+75^{\circ}\text{C}$			
Relative humidity:	0 - 100%			
Temperature sensor:	Optional			Standard for split cell
Accuracy:	$\pm 0.5^{\circ}\text{C}$			

2 INSTALLATION

The load cell support surface should be smooth and perpendicular to the axis of the anchor or tieback. The use of a load bearing plate of suitable thickness between cell base and the bearing surface, and a load distribution plate between the anchor or tieback head and the load cell is required.

Load distribution on bearing plates that are too thin or improperly dimensioned will result in uneven load distribution causing erroneous results. The inside diameter of the load bearing and distribution plates should be identical to the inside diameter of the load cell.

The load distribution plate can be either a single plate or double spherically seated plates. Use of latter can compensate for misalignment of the bearing surface, load cell and distribution plate. Upon installation, locate the electrical connector downward to minimize the risk of damage.

Connector on load cell	P-3500 connection	P-3500 color code
A	P+	RED
B	S+	GREEN
C	S-	WHITE
D	P-	BLACK

TABLE 1: Wiring code for connecting load cell to a P-3500 readout unit.

3 DATA READING AND ANALYSIS

3.1 GENERAL

Each load cell comes with a calibration certificate. The certificate lists the sensitivity factor used with a Measurement Group P-3500 strain indicator or equivalent.

Read each load cell immediately prior to installation. Record each reading under no-load conditions. This reading (under no-load), is the basis for calculating subsequent loads.

ANCLO load cells are temperature compensated for a range of -40 °C to +75 °C for equilibrium temperature conditions. It is recommended to protect it from direct sunlight.

If there is a wide discrepancy during storage temperature of the cell and the ambient temperature prior to installation, the cells should be conditioned to the ambient temperature until temperature equilibrium is reached. This ensures that initial reading, made under no-load conditions prior to installation, is a stable value to which subsequent measurements can be referenced.

ANCLO load cells can be read with most strain gage indicators. The following procedure applies to the P-3500 indicator.

3.2 CALCULATING THE GAGE FACTOR

To determine the load (and the units of load) sensed by the ANCLO load cell and indicated by the P-3500, calculate the gage factor (G.F.) using the formula below and set the P-3500 gage factor using the gage factor button (4) to this value. (Refer to section 3.3 reading procedures).

$$G.F. = \frac{S \times 4000}{F.S.C.}$$

Where:

G.F.	=	Gage factor P-3500 set on the strain gage indicator
S	=	Load cell sensitivity from calibration data sheet and identification plate on the load cell
F.S.C.	=	Full Scale Count i.e. the number of readout units displayed that corresponds to the full scale of the load cell

The G.F. is inversely proportional to the F.S.C., and the F.S.C. must be chosen such that:

$$0.9 < G.F. < 4$$

These values are approximate. A value greater than 0.9 will ensure stable readings. A value less than 4 will ensure good sensitivity.

Sample G.F. determination:

If	Load cell	=	Anclo -2000
	Capacity C	=	2000 kN
	Sensitivity S	=	2.000 mV/ V
	Gage factor G.F.	=	1.000 (P-3500 readout)
	Initial reading L _o	=	100 readout units
	Current reading L	=	1700 readout units
	Readout unit constant	=	4000
	U	=	0.25 kN/unit (P-3500 display unit value)
	P	=	Load in kN

Assume a G.F. of 1.000

$$F.S.C. = \frac{S \times 4000}{G.F.}$$

$$F.S.C. = \frac{2.000 \text{ mV/V} \times 4000}{1.000}$$


$$F.S.C. = 8000 \text{ units}$$

$$\text{and } U = \frac{C}{F.S.C.}$$

U can be increased to a suggested maximum of 1.0 kN / unit using a G.F. of 4.000, the maximum suggested G.F. value.

3.3 READING PROCEDURES

Read the ANCLO load cell using the P-3500 readout as follows:



1. Select BRIDGE FULL (10) and MULT X1 (9)
2. Connect the cell to the binding posts, P+/- and S+/-
3. Push the RUN button (6) and allow the unit to warm up for a few minutes
4. Push the AMP ZERO button (5) and turn the AMP ZERO (2) adjustment until the display reads 0000

5. Push the GAGE FACTOR button (7). Set the gage factor switch (3) to the range corresponding to the gage factor calculated earlier, then rotate the fine adjustment knob (4) until the gage factor is displayed on the LCD(1)
6. Push the RUN button (6), and set the coarse (8) and fine (9) adjustment knobs as required to zero the P-3500 display

NOTE: RECORD THE SETTINGS OF BOTH, THE COARSE AND FINE ADJUSTMENT SETTINGS. THESE NUMBERS ARE VERY IMPORTANT! WITHOUT THE INITIAL BALANCE SETTINGS, ACTUAL LOADS CANNOT BE DETERMINED WITHOUT AGAIN UNLOADING THE CELL.

7. The number displayed will be in the units U as previously calculated
8. Turn the unit power off

Notes:

- A. The gage factor and balance must be individually set prior to reading each cell, these are unique numbers
- B. After initial reading is taken:
Adjust balance controls to the values previously recorded
- C. A sample field data sheet is provided **TABLE 3** on page 9
- D. Refer to **TABLE 1** on page 2 for connecting information
- E. Refer to the P-3500 instruction manual for a complete description of the P-3500

3.4 INTERPRETATION

The AMP ZERO, BALANCE coarse and fine readings must be set and recorded above for both initial and current readings L_0 and L.

Where	P	=	$(L - L_0) U$
	U	=	Value of one P-3500 unit value corresponding to G.F. as described above
	L	=	Current reading in P-3500 units
	L_0	=	Initial reading in P-3500 units
	P	=	Load in units of U

3.5 VERIFICATION OF CELL CIRCUIT

The cell circuit may be checked by reading resistance and comparing it with values below:

- Between P+ and P- wires: 700 ohms (1400 ohms when 8 pairs)
- Between S+ and S- wires: idem
- Other combination between wires: 500 ohms
- Between any wire and ANCLO/structure/shield: >1000 megohms

4 MISCELLANEOUS

4.1 CONVERSION FACTORS

	To Convert From	To	Multiply By
LENGTH	Microns	Inches	3.94E-05
	Millimetres	Inches	0.0394
	Meters	Feet	3.2808
AREA	Square millimetres	Square inches	0.0016
	Square meters	Square feet	10.7643
VOLUME	Cubic centimetres	Cubic inches	0.06101
	Cubic meters	Cubic feet	35.3357
	Litres	U.S. gallon	0.26420
	Litres	Can-Br gallon	0.21997
MASS	Kilograms	Pounds	2.20459
	Kilograms	Short tons	0.00110
	Kilograms	Long tons	0.00098
FORCE	Newtons	Pounds-force	0.22482
	Newtons	Kilograms-force	0.10197
	Newtons	Kips	0.00023
PRESSURE AND STRESS	Kilopascals	Psi	0.14503
	Bars	Psi	14.4928
	Inches head of water*	Psi	0.03606
	Inches head of Hg	Psi	0.49116
	Pascal	Newton / square meter	1
	Kilopascals	Atmospheres	0.00987
	Kilopascals	Bars	0.01
Kilopascals	Meters head of water*	0.10199	
TEMPERATURE	Temp. in °F = (1.8 x Temp. in °C) + 32		
	Temp. in °C = (Temp. in °F - 32) / 1.8		

* at 4 °C

E6TabConv-990505

TABLE 2: Conversion Factors.

4.4 WIRING DIAGRAM




FIGURE 2: ANCLO Load cell wiring diagram (Full Bridge Configuration).